



MASTERPIECES MADE IN GERMANY

Transceiver with IO-Link Interface





H ₂ O	AIR	OIL	GAS	



Device description

The SIGNAL 4.0 IO PRO is a fully digital transceiver for industrial process measurement. The position of a magnetic float / piston is detected by means of a well-proven Hall sensor and transmitted via IO-Link Interface.

Additionally, it is possible to connect external sensors to monitor temperature and pressure. Those signals are then transmitted via the IO-Link Interface.

Application

- Use in combination with float-type sensors for various flow media (see table on page 2)
- Industry 4.0

Characteristics

- IO-Link Interface (IEC 61131-9)
- Internal recording of the flow rate
- Connection of external temperature and pressure sensors possible (Sensors not included)
- Conversion of the analog temperature and pressure signal to IO-Link
- Calculation of viscosity from measured temperature for ISO VG oils
- Same footprint as the proven SIGNAL 4.0
- Housing manufactured with additive manufacturing

Installation information

- Refer also to the applicable data sheets and operating instructions for the flowmeter!
- Additionally, refer to the operating instructions for the transceiver!
- Download: www.meister-flow.com



OPERATING DATA

Accuracy	$\pm 1 \%^{(1)}$	
Operating temperature	0 °C - 70 °C	
Storage temperature	0 °C - 70 °C	

⁽¹⁾ The actual accuracy depends on the flow sensor used. On request the accuracy of the flow sensor used can be significantly increased by a customized calibration.

■ POSSIBLE COMBINATIONS*

Flow		
Monitor	Transceiver	Combination
DUM	+ SIGNAL 4.0 IO PRO	= DUM/IO PRO
DUM/A	+ SIGNAL 4.0 IO PRO	= DUM/A/IO PRO
DWM	+ SIGNAL 4.0 IO PRO	= DWM/IO PRO
DWM/A	+ SIGNAL 4.0 IO PRO	= DWM/A/IO PRO
RVM/U-1	+ SIGNAL 4.0 IO PRO	= RVM/U-1/IO PRO
RVM/UA-1	+ SIGNAL 4.0 IO PRO	= RVM/UA-1/IO PRO
RVM/U-2	+ SIGNAL 4.0 IO PRO	= RVM/U-2/IO PRO
RVM/UA-2	+ SIGNAL 4.0 IO PRO	= RVM/UA-2/IO PRO
RVM/U-4	+ SIGNAL 4.0 IO PRO	= RVM/U-4/IO PRO
WY	+ SIGNAL 4.0 IO PRO	= WY/IO PRO
DKM-1	+ SIGNAL 4.0 IO PRO	= DKM-1/IO PRO
DKM/A-1	+ SIGNAL 4.0 IO PRO	= DKM/A-1/IO PRO
DKM-2	+ SIGNAL 4.0 IO PRO	= DKM-2/IO PRO
DKM/A-2	+ SIGNAL 4.0 IO PRO	= DKM/A-2/IO PRO
DKME-1	+ SIGNAL 4.0 IO PRO	= DKME-1/IO PRO
DKME/A-1	+ SIGNAL 4.0 IO PRO	= DKME/A-1/IO PRO
DWM-L	+ SIGNAL 4.0 IO PRO	= DWM-L/IO PRO
DWM/A-L	+ SIGNAL 4.0 IO PRO	= DWM/A-L/IO PRO
RVM/U-L1	+ SIGNAL 4.0 IO PRO	= RVM/U-L1/IO PRO
RVM/U-L2	+ SIGNAL 4.0 IO PRO	= RVM/U-L2/IO PRO
RVM/U-L4	+ SIGNAL 4.0 IO PRO	= RVM/U-L4/IO PRO



Non-wetted parts	


Housing:

Polyamide

* Further combinations are listed in the operating instructions.



TECHNICAL DRAWING



■ CONNECTION DIAGRAMS

Round plug M12x1, A-coding


Connection for IO-Link (Plug)



Pin assignment

1: 24 V 2: not connected 3: GND 4: IO-Link

Connection for external sensor (Socket)




Pin assignment (Socket)

1: Supply out
2: PT1000
3: GND
4: 0 10 V in
5: PT1000

SIGNAL 4.0 IO PRO 3 0001 01-19 E








LSW = Lower scale value USW = Upper scale value

SIGNAL ROUTING



FI FCTRICAL DATA

Signal output

IO-Link Specification V1.1

Power supply

24 VDC (20 ... 30 VDC)

Power consumption

approx. 1,5 W

Data transfer rate

COM3 (230,4 kBaud)

Notes

IP 65

IP 67

Connection

For round plug M12x1, A-coding 4-pin for IO-Link Interface (Plug)

sensors (Socket)

Ingress protection

Please note that the flowmeter and the SIGNAL 4.0 IO PRO digital transceiver have been optimally adjusted to each other and should not be exchanged! If the unit however needs to be exchanged, a new parameterization is necessary.

5-pin for connection of external temperature and pressure

Please also refer to the data sheets and operating instructions of the respective flowmeter!

Meister Strömungstechnik GmbH • Im Gewerbegebiet 2 • 63831 Wiesen / Germany

Tel. +49 (0) 6096 9720-0 • Fax +49 (0) 6096 9720-30 • sales@meister-flow.com • www.meister-flow.com The general business terms of Meister Strömungstechnik GmbH are valid • All rights reserved

